

LENGTH / MOUNTING DIMENSIONS

RUN CONFIGURATION INFORMATION


ORDERING CODE	LENGTH A*	LENGTH B*	LENGTH C*	LENGTH D*	LENGTH E*
23	22-5/8"	22-3/8"	22-1/8"	16-5/8"	19-3/8"
34	33-5/8"	33-3/8"	33-1/8"	27-5/8"	30-3/8"
45	44-5/8"	44-3/8"	44-1/8"	38-5/8"	41-3/8"
56	55-5/8"	55-3/8"	55-1/8"	49-5/8"	52-3/8"
67	66-5/8"	66-3/8"	66-1/8"	60-5/8"	63-3/8"
78	77-5/8"	77-3/8"	77-1/8"	71-5/8"	74-3/8"
89	88-5/8"	88-3/8"	88-1/8"	82-5/8"	85-3/8"

ORDERING CODE	DESCRIPTION
SN	Single
ST	Starter
AD	Adder
TR	Terminator


* Add 4" to dimension for any fixture using the S1 occupancy sensor option

RUN INFORMATION


Back Plan - Surface Mount Single Fixture Option




Side View - Surface Mount Single Fixture Option



Back Plan - Surface Mount Continuous Run Option




Side View - Surface Mount Continuous Run Option




RUN INFORMATION

Side View - Cable Mount Single Fixture Option



SN

Side View - Cable Mount Continuous Run Option



ST

AD

TR